

SOHO BRICK PANEL INSTALLATION

~REQUIRED MATERIALS AND TOOLS~

- 1) Appropriate amount of brick panels, measure the height and width of the receiving wall, multiply the two measurements and add 10% for wastage.
- 2) Tile set glue (1 gallon will cover approximately 50 square feet). Use heat resistant glue if the installation is close to a source of heat, eg. Wood burning fireplace or stove. The panels themselves are "Class A" fire rated.
- 3) Mortar mix: readily available, normally in 66Lb. bags, sand and masonry cement mix. One bag will cover approximately 60 square feet.
- 4) Mortar bag (resembles a cake decorating bag).
- 5) Level.
- 6) Felt marker.
- 7) Exact-o knife or drywall knife and spare blades.
- 8) Tarp or a roll of plastic for floor protection.
- 9) Flexible 4" wall scraper.
- 10) 3/16" notched trowel for applying the glue.
- 11) Two, 5 gallon pails (one for water and one to mix the Mortar Mix in).
- 12) Drill with a mixer for mixing the mortar.
- 13) Brick pointing tool (a spoon or similar object will do).
- 14) Hard bristle brush, or medium scrub brush.
- 15) Sponge or rag (for goof ups with the glue).